




CABINET PARTS

For Models: LEQ9858LW0, LEQ9858LG0
(White/Grey) (Biscuit/Gold)

29" ELECTRIC DRYER



1
Literature Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: LEQ9858LW0, LEQ9858LG0
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1		Literature Parts
	LIT8535829	Instructions, Installation
	LIT8522243	Use & Care Guide
	LIT3406661	Label, Wiring Diagram

Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

	LIT677818	Dryer
2	343641	Screw, 10-16 x 1/2
3	693995	Screw, 8-18 x 3/8
5	3396795	Cover, Block
6	342043	Screw, 10-32 x 3/8
7	3396805	Panel, Rear
10	3406107	Door Switch Assembly
11	697773	Screw, 6-20 x 7/8
13	3357011	Screw, 10-16 x 1/2
14	692495	Spring, Door (2)
15	3394083	Clip, Front Panel (2)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

16	3392100	Foot, Dryer
	279810	Foot-Optional (Extended Length Package of 2) (Not Included)
17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)
18		Cabinet
	8530603	White
	8530606	Biscuit
19	98234	Clip, Ground
20	690363	Lock, Front Top (2)
21		Panel, Front
	695620	White
	3977244	Biscuit
23	685203	Clip, Felt Pad (3)
24	3389441	Catch, Door Assembly
26	337189	Clip, Hinge (2)
27	694091	Screw, 8-18 x 3/8
28	8066056	Hinge, R.H.
	8066057	Hinge, L.H.
33	696144	Strike, Door
35	695737	Door, Rear


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

36		Door, Front
	3393549	White
	3977241	Biscuit
37		Handle, Door
	690270	White
	3977242	Biscuit
38	3406129	Seal & Bearing Assembly
39	279393	Terminal Block Kit (For Terminal Block)
40	697776	Screw, 10-32 x 5/8
41	3397659	Block, Terminal
42	238088	Hinge, Top (2)
43	3394332	Idler & Slide Assembly
44	8066065	Belt, Drive
45	348780	Base, Motor
46	3400500	Bolt, 5/16-18 x 3/4
47	3394341	Pulley, 60 Hz.
48	661654	Motor Assembly 60 Hz.
49	660658	Clamp, Motor
50	3404162	Clamp, Motor (W/Shield)
51	3390731	Seal, Door
52	3393008	Screw, 10-16 x 1/2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LEQ9858LW0, LEQ9858LG0
(White/Grey) (Biscuit/Gold)



WIRING HARNESS PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LEQ9858LW0, LEQ9858LG0
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console	12	3978605	Hinge, R.H.	29	3390646	Screw, Mounting (8-18 x 5/16)
2	3401695	Wire, Jumper (Buzzer On/Off)		3978606	Hinge, L.H.	30	357213	Nut, Push-In (2)
3	693995	Screw, Hex Head	13	688983	Screw, 8-18 x 5/8	31	8299889	Harness, Wiring
4		Cap, End (L.H.)	14	3400859	Screw, Grounding	33	3397269	Connector (Timer)
	8271365	White	15	3395683	Connector (Motor)	34	3347243	Connector 6-Circuit
	8271368	Biscuit	16		Top	35	94614	Terminal
5	3405154	Switch, Wrinkle Shield		8271390	White	39	3398094	Switch, Push-To-Start
6	388326	Screw, Console		8271392	Biscuit	48		Timer Knob Assembly
7	694419	Buzzer, Mini	17		Knob, Control (3)		8316538	(For LEQ9858LW0)
8		Cap, End (R.H.)		8316540	(For LEQ9858LW0)		8316549	(For LEQ9858LG0)
	8271359	White		8316545	(For LEQ9858LG0)	50	3936144	Connector
	8271362	Biscuit	18	3394427	Clip-Harness	51	3390537	Control, Electronic
9	8528330	Switch, Temperature	19	297535	Bumper, Lint Lid	52	3391885	Connector, Edge
10	349639	Screen, Lint	20	3401144	Connector, (PTS Relay)	53	8271418	Bracket, Control
11		Cover, Lint	21	3406725	Timer, 60 Hz.	54		Panel, Control (Includes Illus. 24)
		Screen	22	3405152	Switch, End Of Cycle		8532631	Grey
	8283378	White	23		Knob, Push-To-Start		8532632	Gold
	8283380	Biscuit		8316541	(For LEQ9858LW0)	55	343641	Screw, 10-16 x 1/2
				8316546	(For LEQ9858LG0)			
			24	3955775	Medallion			

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ACCESSORY PARTS

279948 Kit,
Dryer Repair
3406839 Dry Rack
8522199 Kit, Dryer
Vent Testing

PAINT, TOUCH-UP (1/2oz.)

72017 White
4392899 Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White
4392901 Biscuit
350938 Primer, Gray


PAINT, BULK (1 qt.)

799344 White (Uncut)
4392900 Biscuit (Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LEQ9858LW0, LEQ9858LG0
(White/Grey) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LEQ9858LW0, LEQ9858LG0
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	487909	Screw, 8-15 x 1/2
3	3388703	Washer-Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8-18 x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	8318268	Thermostat, Internal-Bias
9	3977393	Thermal Cut-Off (Includes Illus. 15)
10	694089	Wheel, Blower (Includes Illus. 22)
11	3405016	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10-16 x 1/2
14	3397566	Box, Heater
15	3977767	Thermostat, 221°F (105°C)
16	3977373	Bracket, Drum Light
17	3403585	Element, Heater
18	8066086	Drum Hole Plug
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
20	489463	Screw, 8-18 x 5/8
22	3394196	Seal, Blower
24	3390647	Screw, 8-18 x 1/2
30	3976479	Pad, Sensor
33	3406124	Bulb
34	3402841	Lens, Drum Light
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	3403414	Bulkhead
49	3403634	Socket Assembly
50	692526	Ring, Bearing (2)
51	97787	Screw, 11-16 x 3/4
52	3406130	Seal, Rear Drum
53	695587	Drum Assembly
54	692490	Baffle, Drum (2)
55	3976434	Bracket, Support
56	90296	Clip
57	3403636	Baffle, Drum (1)
58	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST